

Quick Installation Guide

Model # AKVM-4



Section 1

Introduction

The **AKVM-4 switch** is a 4-port PS/2 type KVM switch that comes with 3-in-1 combo KVM cables to save you cabling troubles. It enables users to access, control, boot, and reboot up to 4 computers using only one keyboard, video monitor, and mouse. It can be your best companion for managing 2 to 4 computers on either SOHO or corporate desktop.

Section 2

Installation



Before connecting any cable, please make sure all of your computers and their peripherals have been powered off. Otherwise, the KVM switch may not be set up properly.

Step 1 Make sure all the computers that are to be connected to the KVM switch and their peripherals are powered-off. If not, power them off before you proceed with the following steps.

Step 2 Connect the shared keyboard, monitor, and mouse to the main KVM unit. See Fig. 1.1




Fig 1.1

Step 3 Connect each of your computer to the KVM switch using the provided 3-in-1 combo KVM cables. See Fig. 1.2



Fig 1.2

You can use individual standard keyboard, mouse and video cables to extend the cable distance, but depending on the type of cables you use, the maximum cable distance is limited to 5 ~ 7 meters (15.5 ~ 23 feet).

Step 4 Power up the connected computers one by one. After the computers are powered up, the keyboard and mouse will be recognized and you can begin operating the KVM switch.

Section 3

Operations

There are two methods to select a specific computer:

Using the **push button** or the **hotkey sequence**.

Push Button

The push button lets you directly switch between the computers. Simply press the applicable button on the KVM unit to select the corresponding computer.

Hotkey Sequence

The hotkey sequence consists of three specific keystrokes pressed on the keyboard.

Hotkey sequence = **ScrLk + ScrLk + Command key**
The two consecutive **ScrLk** key should be pressed within 2 seconds and the following command key(s) should also be pressed within 2 seconds. Otherwise, the hotkey sequence will not be validated.

For detailed Hotkey sequences and their corresponding functions, please refer to the Quick Reference Chart on back.

Section 4

Technical Support

Email: support@airlinkplus.com

Website: www.airlinkplus.com

Continue on Back



Quick Reference Chart

Command	Hotkeys	Front-Panel Button	Description
Select PC	ScrLk + ScrLk + (channel #) ¹	Press the applicable button for the corresponding computer	Select the active channel
Next lower channel	ScrLk + ScrLk + (up arrow)		Select the next lower channel
Next higher channel	ScrLk + ScrLk + (down arrow)		Select the next higher channel
Autoscan Beep Sound On/Off	ScrLk + ScrLk + B		Toggle on/off the beep sound while autoscanning
Reset KVM	ScrLk + ScrLk + End		Reset the KVM Switch
Autoscan	ScrLk + ScrLk + S		Autoscan through every connected channel
Stop Autoscan	Any key on keyboard		Terminate Autoscan activity

¹ Press 1, 2, 3, or 4 for the channel #